

# Spray adhesive Tarkospray - Residential

**ADHESIVES & WELDING** 

## **DESCRIPTION**

High grade acrylic adhesive delivered in an aerosol can for DIY'er customers (modern distribution).

#### Key features:

- Easy and safe: no tools required, zero CFC, non toxic, non flammable.
- Same quality as professionals use.
- Eco-friendly: 80% less glue doing the same job, low emission, reduced carbon footprint.
- Time saving, with a quick (70% faster) and removable application.
- Ideal for easy renovation, and environment friendly.

#### Compatible flooring:

- Mainly for vinyl floors.
- Carpet tiles (with PVC backing).

#### Main segments of application:



# **TECHNICAL INFORMATION**

Product		
Unit weight (g)	567 (12m²)	
Packaging		
Pieces per box	12	
Box size (cm)	48 x 17 x 33	
Box weight (kg)	7.39	
Pallet size (m)	1.0 x 1.12 x 0.86	
Pallet weight (kg)	250	
Min. order	1 box	

## **ARTICLE CODE**

Languages	SAP Code EAN Code	
English, French, German, Dutch, Polish	1460 003	094922378797
English, Swedish, Spanish, Italian, Portuguese	1460 008	1094922319929



#### INSTALLATION

- The subfloor must be level, flat, clean, free from marks, dry, solid, smooth and not exposed to moisture.
- The building, subfloor, flooring and adhesive must be acclimatized to a minimum 15°C.
- Store adhesive at 15°C minimum temperature for 24 hours prior to installation.
- Ensure subfloor, flooring and surrounding areas are clean and dust free. Damp-mop the subfloor if dust is present (you can check with a white cloth).
- Shake the aerosol can well and remove the cap.
- Hold the can horizontal approximately 50-76 cm above the substrate and spray adhesive smoothly walking right to left, respecting density of flakes.
- Allow adhesive to dry until there is no transfer when touched lightly.
- Lay down your flooring into the adhesive
- Complete bond by applying pressure.

## **CLEANING & MAINTENANCE**

Adhesive stains can be removed with damp sponge when still fresh or with white gas later on.

